PULSAR

INLINE CONTROL MODULE
LT

PULSAR
LT

PROGRAMMING MENU [repeat for each feature]

1. Engine Off
2. a. Using a push button – Foot off brake, Press and hold Start button 5 sec.
   b. Using a key – turn key to the RUN position
3. Hold Cancel Cruise button 5 sec.
4. Navigate with +RES/–SET to feature
5. Press Cancel Cruise to select feature

Speed Limiter — 10

1. Select 10 (MPH)
2. Adjust with +RES/–SET
3. Press Cancel Cruise to select

TPMS
(Tire Pressure Monitor System) — 20

1. Select 20 (MPH)
2. Adjust with +RES/–SET
3. Press Cancel Cruise to select

Tire Size — 30

1. Select 30 (MPH)
2. Select stock whole number then press Cancel Cruise to save
3. Select stock decimal number then Cancel Cruise to save
4. Repeat 2-3 with modified tire size

Axle Ratio — 40

1. Select 40 (MPH)
2. Select stock whole number then press Cancel Cruise to save
3. Select stock decimal number then Cancel Cruise to save
4. Repeat 2-3 with modified axle ratio

Clear DTC's — 50

1. Select 50 (MPH)
2. Press Cancel Cruise to select

AFM/DFM
(Fuel Management) — 60

1. Select 60 (MPH)
2. Adjust with +RES/–SET
   a. 0 = Active
   b. 10 = Disabled
3. Press Cancel Cruise to select

* For complete instructions please refer to the user manual